



®

Product Specification

PORTER'S INTERIOR DISTEMPER

PRODUCT DESCRIPTION:

Porter's Interior Distemper is one of the simplest and most traditional interior paints. Interior Distemper is a superbly creamy paint that dries to a velvet-like finish with very subtle tone variations. Based on an original recipe that uses powdered chalk, pigments and binders. As well as lending itself to modern interiors, Interior Distemper is widely used in the restoration of heritage and trust houses, giving them back their original elegance and stylish simplicity. Optionally, Distemper Paste can be added to the paint to create more obvious variations in colour and a lighter, more "aged" finish. For a subtle variation in colour tone, leave the paste out. Can be protected and made wipeable with the application of Matt Wall Sealer or Porter's Stucco Wax. Stucco Wax, when dried and buffed, creates a finish like polished leather.

LOCATION:

Interior.

ENVIRONMENTAL INFORMATION:

This product contains: <32.62g/L VOC's untinted (Volatile Organic Compounds contribute to atmospheric pollution).

The following descriptors have been adopted by APAS (Australian Paint Approval Scheme):

Very High	>250 g/L
High	100 – 249 g/L
Moderate	50 – 99 g/L
Low	5 – 49 g/L
Very Low	<5 g/L

This product is classified as Low VOC by the Australian Paint Approval Scheme.

Porter's Paints use only premium grade raw materials and wherever possible we buy from Australian suppliers. Our manufacturing processes are designed for maximum performance with minimum impact on the environment and user health.

SUGGESTED APPLICATIONS:

Can be applied to most suitably prepared plasterboard, plaster, masonry and previously painted surfaces. Not recommended for bathrooms, wet areas or kitchens.

COLOURS:

Choose from our range of colours or ask our colourist for your own custom colour.

A subtle colour variation is a characteristic of Interior Distemper, more so when the Distemper Paste has been added. This effect is more evident in darker and deeper colours and less so in pale, light colours.

COMPARISON TO INTERNO LIME WASH:

Interior Distemper is less reactive to low substrate temperatures than Interno Lime Wash. Low temperatures during application can cause Interno to create an excessive white "bloom", whereas Interior Distemper is more stable and less inclined to turn white.

When using Interior Distemper, the amount of “bloom” can be controlled with how much paste is added. The bloom from Interno Lime Wash cannot be controlled.

Interior Distemper has a more natural looking tonal variation. Interno Lime Wash can develop a high degree of colour variation with an emphasis on brush marks, whereas Interior Distemper has a softer more velvet-like look.

LIMITATIONS:

Do not apply in high humidity, below 10°C or above 30°C. May develop a slight sheen if painted on a very cold day, or onto a very cold substrate. Not suitable for application to wood. Completed work cannot be retouched as a distinct mark will show. Interior Distemper has a very long shelf life until the addition of Distemper Paste - after paste has been added the paint will begin to thicken and must be used immediately.

In medium to high traffic areas that will require cleaning or washing, protect with Matt Wall Sealer or Stucco Wax, as Interior Distemper is not washable on its own.

PREPARATION:

Substrate should be a clean well-held surface free from loose material, dirt, grease, oil and mould. Dust down before proceeding.

On new unpainted plasterboard sheeting spot prime all joints then apply by brush, roller or spray 1 or 2 coats Porter's Prepare & Prime. Allow 2 hours dry time before overcoating.

On new unpainted fresh set plaster do not proceed until plaster has thoroughly set and has dried completely. Firstly, apply 1 coat Porter's Mineral Silicate Primer by brush or roller. Touch dry 20 minutes. Allow 2 hours dry time. Then apply by brush, roller or spray 1 coat Porter's Prepare & Prime. Allow 2 hours dry time before recoating or overcoating with top coat.

On bare masonry surfaces such as, render or brick, spot prime all repaired areas with Porter's Limeproof Undercoat Sealer, then apply 1 coat of same to entire area by brush, medium nap roller or spray. Touch dry in 1 hour. Allow 6 hours dry time before recoating or over-coating.

PLEASE NOTE:

If a wall has variations in porosity, this will be evident as obvious marks in the final coat of Distemper, so we stress the importance of correct preparation of the substrate.

PREVIOUSLY PAINTED SUBSTRATES:

All varnishes, polyurethanes or surfaces previously painted with water-based acrylic paint or oil-based enamel paint should be thoroughly sanded to remove gloss and to create a “keyed” surface. Loose, peeling or flaking paint must be made sound by scraping off loose paint. Fill nail holes and cracks with suitable filler, sand and dust off. Spot prime all joints and repaired areas with either Porter’s Prepare & Prime, then apply one coat of same to entire area.

Allow 2 hours dry time before recoating or overcoating with top coat.

DISTEMPER PASTE

Distemper Paste is supplied in pre-measured quantities with each container. The paste contains lime, which creates colour variations and blooming effects as the paint dries. The contrast between the lime (which is white) and the pigment of the chosen colour create the movement in the finish. This is accentuated in deeper colours and becomes softer and less evident with lighter ones. The amount of paste can be partially reduced or left out completely for a subtler effect.

PLEASE NOTE: When Distemper Paste is added the colour will become slightly lighter (20–30% lighter). Please consider this when viewing samples or choosing colours direct from the Porter’s fan deck.

APPLICATION:

Stir thoroughly prior to use. If required, add Distemper paste to can and stir thoroughly. Apply two coats by Distemper brush (4x14cm block brush) using a “crow’s feet” or random painting technique. Cutting in should be completed progressively as you move across the wall surface. Care must be taken to maintain a wet edge, especially during hot and dry conditions. Interior Distemper will show a joint if the wet edge is allowed to dry mid-wall. Plan for work stoppage to occur at corners, or vertical moldings. Touch dry in 2 hours. Allow minimum 12 hours dry time between coats. Allow 12 hours dry time.

COVERAGE RATES:

Covers approximately 10m² per litre, depending upon porosity, surface texture and wastage rates.

WASH UP:

Water.

COMPLEMENTARY PRODUCTS:

Porter's Prepare & Prime (coverage 12-14m² per litre).

Porter's Limeproof Undercoat Sealer (12m² per litre).

Mineral Silicate Primer (coverage 10m² per litre) is recommended for priming new set plaster before undercoating.

Porter's Matt Wall Sealer (coverage 15m² per litre) may be applied over the finished job where improved durability is required. Allow Distemper to dry for a minimum of 7 days prior to the application of Matt Wall Sealer. Matt Wall Sealer may deepen colours or slightly alter the appearance of Interior Distemper.

Porter's Stucco Wax may be applied over the finished job where improved durability is required. May be buffed for a leather-like finish. Please be aware that Stucco Wax will make the Distemper colour appear darker. Allow Distemper to dry for a minimum of 7 days prior to the application of Stucco Wax.

PACKAGING:

Porter's Interior Distemper is available in 1 litre, 4 litre & 15 litre sizes.

STORAGE:

Store in a cool dry area, protected from frost.

PRECAUTIONS:

Keep out of reach of children. Avoid swallowing. Avoid eye contact. Avoid prolonged skin contact. Provide adequate ventilation. If accidental contact occurs, rinse immediately with water. Check colour before use.

MANUFACTURER'S/DISTRIBUTOR'S DETAILS:

Porter's Paints

15 Gow St

Padstow NSW 2211

Australia

Phone: (02) 9698-5322

Toll free: 1800 656 664

Fax: (02) 9699-5322

E-mail: enquiries@porters.com.au

Web: www.porterspains.com

Porter's Paints

150 Hutt Park Rd

Gracefield

Lower Hutt 5010

New Zealand

Ph: 0800 672 468